

GRYPHON™ GPS4400 UPC / EAN OPTIONS

UPC-A Options

UPC-A = Disable



UPC-A = Enable



UPC-A Check Digit = Disable



UPC-A Check Digit = Enable



UPC-A Expand to EAN 13 = Disable



UPC-A Expand to EAN 13 = Enable



UPC-A, NSD = Disable



UPC-A, NSD = Enable



UPC-E Options

UPC-E = Disable



UPC-E = Enable



UPC-E Check Digit = Disable



UPC-E Check Digit = Enable



UPC-E Expand to EAN 13 = Disable



UPC-E Expand to EAN 13 = Enable



UPC-E Expand to UPCA = Disable



UPC-E Expand to UPCA = Enable



UPC-E, NSD = Disable



UPC-E, NSD = Enable



EAN-13 Options

EAN13 = Disable



EAN13 = Enable



EAN13 Check Digit = Disable



EAN13 Check Digit = Enable



EAN13, NSD = Disable



EAN13, NSD = Enable



EAN 8 Options

EAN8 = Disable



EAN8 = Enable



EAN8 Check Digit = Disable



EAN8 Check Digit = Enable



EAN8 Expand to EAN 13 = Disable



EAN8 Expand to EAN 13 = Enable

